

Description	NSN	Part No.
<u>AMPLIFIER,DIRECT CURRENT</u>	<u>#5996-01-358-5847</u>	<u>#IFAD-7522-0100</u>
<u>AMPLIFIER,DIRECT CURRENT</u>	<u>#5996-01-358-5846</u>	<u>#IFAD-7522-0030</u>
<u>AMPLIFIER,DIRECT CURRENT</u>	<u>#5996-01-358-5845</u>	<u>#IFAD-7522-0015</u>
<u>AMPLIFIER,DIRECT CURRENT</u>	<u>#5996-01-358-5844</u>	<u>#IFAD-7522-0008</u>
<u>AMPLIFIER,DIRECT CURRENT</u>	<u>#5996-01-358-5843</u>	<u>#IFAD-7522P-0050</u>
<u>AMPLIFIER,DIRECT CURRENT</u>	<u>#5996-01-358-5842</u>	<u>#IFAD-7522-0020</u>
<u>AMPLIFIER,DIRECT CURRENT</u>	<u>#5996-01-358-5841</u>	<u>#IFAD-7522-0010</u>
<u>AMPLIFIER,DIRECT CURRENT</u>	<u>#5996-01-358-5840</u>	<u>#AMA-8801</u>
<u>AMPLIFIER,DIRECT CURRENT</u>	<u>#5996-01-358-5839</u>	<u>#AM-8801M</u>
<u>MODULE,VOLTAGE TUN</u>	<u>#5895-01-358-5774</u>	<u>#VTF-8801</u>
<u>MODULE,LOW PASS</u>	<u>#5895-01-358-5771</u>	<u>#A-333</u>
<u>CONVERTER,SIGNAL DATA</u>	<u>#5895-01-540-7976</u>	<u>#2055</u>
<u>MODULE,SYNTHESIZER</u>	<u>#5895-01-358-5773</u>	<u>#SYN-8501</u>
<u>MODULE,MICROPROCESS</u>	<u>#5895-01-358-5790</u>	<u>#UPC-8808/1</u>
<u>MODULE,POWER SUPPLY</u>	<u>#5895-01-358-5782</u>	<u>#A-387</u>
<u>MODULE,SYNTHESIZER</u>	<u>#5895-01-358-5778</u>	<u>#HIRESYN-8801</u>

Description	NSN	Part No.
<u>MODULE,AUDIO-VIDEO</u>	<u>#5895-01-358-5789</u>	<u>#AVA-8808</u>
<u>MODULE,FREQUENCY</u>	<u>#5895-01-358-5777</u>	<u>#FTL-8801</u>
<u>MODULE,REF,FREQUENC</u>	<u>#5895-01-358-5786</u>	<u>#RFG-8801Q</u>
<u>MODULE,POWER SUPPLY</u>	<u>#5895-01-358-5781</u>	<u>#A-386</u>
<u>MODULE,REFERENCE O</u>	<u>#5895-01-358-5787</u>	<u>#A-339</u>
<u>MODULE,POWER DIVIDE</u>	<u>#5895-01-358-5788</u>	<u>#PD-8810</u>
<u>MODULE,REF,FREQUENC</u>	<u>#5895-01-358-5791</u>	<u>#RFG-8801M</u>
<u>RECEIVER,VLF</u>	<u>#5895-01-549-9301</u>	<u>#VLF-2055</u>
<u>MODULE,BANDPASS FI</u>	<u>#5895-01-358-5779</u>	<u>#A-341</u>
<u>MODULE,UPROCESSOR</u>	<u>#5895-01-358-5780</u>	<u>#UPC-8808/1-4</u>
<u>MODULE,PRESELECTOR</u>	<u>#5895-01-359-4279</u>	<u>#RFP-8801</u>
<u>MODULE,BANDPASS</u>	<u>#5895-01-358-6864</u>	<u>#BPF-8801</u>
<u>MODULE,IF CONTROL</u>	<u>#5895-01-358-5772</u>	<u>#IFC-8808</u>
<u>MODULE,POWER DISTRI</u>	<u>#5895-01-358-5783</u>	<u>#PSD-8802</u>
<u>MODULE,BANDPASS FI</u>	<u>#5895-01-358-5776</u>	<u>#A-340</u>
<u>MODULE,POWER DIVIDE</u>	<u>#5895-01-358-5785</u>	<u>#PD-8810-1</u>

Description	NSN	Part No.
<u>MODULE,HARMONIC GE</u>	<u>#5895-01-358-5775</u>	<u>#HRG-8501</u>
<u>MODULE,LINE FILTER</u>	<u>#5895-01-358-5784</u>	<u>#LFA-8801</u>
<u>RECEIVER,RADIO</u>	<u>#5895-01-421-7263</u>	<u>#9450</u>